
VisionGuard AI-Powered Driver Drowsiness Monitoring

A modular prototype that turns eye-state and yawning evidence into transparent, rule-based drowsiness warning candidates — in real time and from uploaded video.

Deep Learning Group Project · UTS · Live System Demo



Drowsiness is a multi-cue, time-based signal — not a single snapshot

- 01 Drowsy driving is safety-critical, yet a single frame rarely proves fatigue on its own.
- 02 The real cues live in the eyes and the mouth, and they only become convincing over several seconds.
- 03 A single end-to-end “drowsy / not-drowsy” box hides its reasoning and tends to break on unseen drivers.
- 04 Cameras fail: a turned head or a lost face must never be read as drowsiness.
- 05 A driver-assist tool should surface explainable evidence, not deliver a medical verdict.

Split the problem into specialist visual signals, then fuse them over time with transparent rules.

VISIONGUARD DESIGN PRINCIPLE

2

Specialist CNN models


5

Rule-based warning states


0

Black-box verdicts

Scope: VisionGuard outputs rule-based warning candidates and signal-quality flags — not a final system-level or medical drowsiness judgment.



From raw datasets to a live, explainable system



Two complementary datasets, each split by subject

84,898 images

MRL Eye open / closed corpus

Near-balanced: 41,946 closed vs 42,952 open.

64,202 mouth crops

YawDD + YawDD+ Dash yawning

99.73% crop success via MediaPipe lip landmarks.

37 subjects

MRL Eye — eye specialist

Split 25 / 6 / 6 across train · val · test.

29 drivers

YawDD Dash — mouth specialist

Split 20 / 4 / 5 across train · val · test.

100% subject-level

No driver appears in two splits

Prevents identity and frame leakage across splits.

2 label sets

closed / open · no_yawn / yawn

Specialist labels — not end-to-end drowsiness labels.

Training data prep — the YawDD mouth pipeline

1

Reconstruct frames

YawDD+ frame index and class labels rebuild labeled full frames from the YawDD raw Dash videos.

2

Mouth crops

MediaPipe Face Mesh / FaceLandmarker lip landmarks crop the mouth region (99.73% success).

3

Haar fallback

OpenCV Haar lower-face crop when MediaPipe fails; failed crops are dropped and never used for training.

4

Subject split

Partition by driver so train, val, and test never share an identity.

MRL Eye already provides cropped eye images, so the eye specialist needs no frame reconstruction. Runtime is separate: from live webcam or uploaded video, both eye and mouth ROI are extracted per frame.

Each component owns one visible behavior

98.6%

MRL Eye · MobileNetV2 → p_eye_closed

Eye open / closed specialist, selected as the runtime eye model for its accuracy and latency balance.

- Macro F1 98.6% on held-out subjects
- Closed-eye recall 98.5%
- Decision threshold $p \geq 0.50$

✓ **Selected runtime eye model**

99.4%

YawDD Mouth · ResNet18 → p_yawn

Mouth / yawn specialist trained on subject-split Dash mouth crops.

- Yawn F1 97.2%
- Yawn recall 97.9%
- Best of three CNN baselines

✓ **Selected runtime mouth model**

Rules

Temporal fusion → warning states

No trained fusion model — a transparent rule layer combines both signals over time with a quality gate.

- Five warning-candidate states
- PERCLOS-like proxy from rolling p_eye_closed
- Quality gate for lost-face frames

✓ **Fully explainable**

Two-stage transfer learning on ImageNet backbones

Backbones & classifier head

- ImageNet-pretrained ResNet18, MobileNetV2, EfficientNet-B0
- ImageNet head replaced with a new 2-class `nn.Linear` head
- A standard PyTorch layer — not a custom or third-party head

Two-stage transfer

- Stage 1: freeze the backbone, train the new classifier head
- Stage 2: unfreeze the full backbone for fine-tuning

Optimization

- Loss: weighted `CrossEntropyLoss`
- Optimizer: Adam (mouth / yawn), AdamW (MRL eye)

Inputs & split

- 224×224 RGB with ImageNet normalization
- Subject-level train / val / test split — no identity leakage

Specialist test accuracy across three CNN baselines



Subject-level test accuracy; bars scaled to a 97.5–100% window for contrast. Metrics are within-task specialist results — mouth and eye accuracies are not one unified drowsiness benchmark, and not final system-level drowsiness accuracy.

How warning states emerge from evidence over time

Eye evidence over time

- PERCLOS-like proxy from rolling `p_eye_closed`
- Eye warning when rolling mean ≥ 0.60
- Enter / exit hysteresis resists flicker

Mouth / yawn evidence

- `p_yawn` per mouth crop, thresholded to yawn events
- Recent-yawn context: 4 s live, 8 s upload
- A yawn alone is a candidate, not a verdict

Signal-quality gate

- Track the no-face / lost-ROI ratio
- Flag `signal_unreliable` when faces are missing
- Tracking failure is not drowsiness evidence

Persistence rules

- Require consecutive frames before alerting
- Debounce and cooldown on each alert kind
- High confidence needs sustained eye + recent yawn

Five candidate states

- `normal` · `eye-warning` · `mouth-warning`
- high-confidence drowsiness candidate
- signal unreliable

Demonstrated on a controlled clip

- 103 sampled frames, F5 tiered rule
- 18 eye-warning, 30 mouth-warning frames
- 6 high-confidence frames where both overlap
- Controlled-demo warning-candidate output — not final accuracy

Live Monitor

Video Upload Analysis

History

Insights

VisionGuard
Driver Drowsiness System

Live Monitor

Video Upload Analysis

History

Insights

System Status
All systems operational

Live Monitor

LIVE

CURRENT DRIVE 00:14:33


Day

1

DRIVER
John_Coffey

Camera Active

Webcam



Stop Camera

EYES CLOSED
2 events

YAWN
1 events

Drowsiness Risk

REALTIME




Low

20 / 100

Monitoring

Drowsiness Level (Last <1 Min)

Idle Low Medium High



Recent Events


Today

- 01:06:26 Critical Eye Warning
- 01:06:23 Normal
- 01:06:20 Yawn Warning
- 01:06:11 Critical Eye Warning

Expand events >

This output is a realtime rule-based warning-candidate analysis, not final system-level drowsiness accuracy.

Archive: Saved stable Live Monitor event to local backend archive.



From Evidence to Awareness

Live demo in three steps — start the camera and trigger an eye-closure warning, upload a clip to review fused intervals and keyframes, then open History & Insights to see the trail.

[Start the Live Demo](#)

VisionGuard · Rule-based warning candidates, not a final drowsiness verdict · Thank you